

Hamlet

4 PORT USB 3.0 5 Gigabit SuperSpeed Hub



Manuale Utente

XHUB430BK
XHUB430BKPW

www.hamletcom.com

Gentile Cliente,
La ringraziamo per la fiducia riposta nei nostri prodotti. La preghiamo di seguire le norme d'uso e manutenzione che seguono. Al termine del funzionamento di questo prodotto La preghiamo di non smaltirlo tra i rifiuti urbani misti, ma di effettuare per detti rifiuti una raccolta separata negli appositi raccoglitori di materiale elettrico ed elettronico o di riportare il prodotto dal rivenditore che lo ritirerà gratuitamente.

Informiamo che il prodotto è stato realizzato con materiali e componenti in conformità a quanto previsto dalle Direttive RoHS 2011/65/EU & 2015/863/EU, RAEE 2002/96/CE, 2003/108/CE D.lgs. 151/2005 e dalle Direttive EMC 2014/30/EU e LVD 2014/35/EU per i seguenti standard:
EN 55032: 2015/AC: 2016, EN 61000-3-2: 2014, EN 61000-3-3: 2013, EN 55035: 2017, EN 62368-1: 2014 + A11: 2017.



La dichiarazione di conformità CE completa relativa al prodotto può essere richiesta contattando Hamlet all'indirizzo e-mail info@hamletcom.com.
Visita www.hamletcom.com per informazioni complete su tutti i prodotti Hamlet e per accedere a download e supporto tecnico.
Importato da: CARECA ITALIA SPA - Scandiano (RE) - Italia.

Marchi e variazioni

Tutti i marchi e i nomi di società citati in questa guida sono utilizzati al solo scopo descrittivo e appartengono ai rispettivi proprietari.
La presente guida ha scopo puramente informativo. I contenuti, le specifiche e le caratteristiche esteriori del prodotto sono indicative e possono variare senza obbligo di preavviso.

Descrizione

Hamlet 4 Port USB 3.0 è un Hub esterno che aggiunge quattro porte USB 3.0 al vostro computer. Supporta fino a 4 periferiche USB ed è compatibile con il nuovo standard SuperSpeed USB 3.0 che offre una velocità di trasferimento dati fino a 5 Gbps, 10 volte più veloce di USB 2.0.

Requisiti di sistema

- Windows 7/8/10 e 11, Mac OS 10.8 o sup., Linux (kernel 3.0 e seguenti)
- Porta USB 3.0 per prestazioni USB 3.0

Contenuto della confezione

- Hub USB 3.0
- Cavo USB 3.0
- Alimentatore (solo XHUB430BKPW)
- Manuale utente

Installazione ed Utilizzo del prodotto

1. Collegare il connettore micro USB alla porta micro USB dell'Hub utilizzando il cavo USB 3.0 in dotazione.
2. Collegare l'altra estremità del cavo USB ad una porta USB 3.0 del computer.
3. Solo per il modello XHUB430BKPW, collegare l'alimentatore al connettore di alimentazione dell'unità e alla presa di corrente a muro.
4. Connettere i dispositivi USB alle porte USB 3.0 dell'Hub.
5. I dispositivi collegati verranno riconosciuti dal sistema e la relativa icona verrà visualizzata in "Risorse del computer" (Windows) o sulla "Scrivania" (Mac).

Scollegare dispositivi USB

Se il dispositivo è dotato di una spia di attività, prima di scollegarlo attendere qualche secondo dopo che la spia ha smesso di lampeggiare.

Utenti Windows

Se viene visualizzata l'icona "Rimozione sicura dell'hardware" nell'area di notifica nella parte destra della barra delle applicazioni, è possibile utilizzarla per rimuovere il dispositivo.

1. Fare clic sull'icona "Rimozione sicura dell'hardware".
2. Fare clic sull'unità che si desidera scollegare.
3. Viene visualizzato il messaggio: "Rimozione sicura dell'hardware" o un altro messaggio equivalente. A questo punto la periferica può essere rimossa senza alcun problema.

Utenti Mac

Per espellere un disco o un volume, eseguire una di queste operazioni:

- Selezionare l'icona dell'elemento da espellere e scegliere Archivio > Espelli.
- Trascinare l'icona dell'elemento sull'icona del Cestino nel Dock (l'icona del Cestino si trasforma in icona di espulsione).

Hamlet

4 PORT USB 3.0 5 Gigabit SuperSpeed Hub



User Manual XHUB430BK XHUB430BKPW

www.hamletcom.com

Dear Customer,
Thanks for choosing a Hamlet product. Please carefully follow the instructions for its use and maintenance and, once this item has run its life span, we kindly ask You to dispose of it in an environmentally friendly way, by putting it in the separate bins for electrical/electronic waste, or to bring it back to your retailer who will collect it for free.

We inform You this product is manufactured with materials and components in compliance with RoHS Directives 2011/65/EU & 2015/863/EU, WEEE Directive 2002/96/CE, 2003/108/CE Italian Legislative Decree 2005/151, EMC Directive 2014/30/EU and LVD Directive 2014/35/EU for the following standards: EN 55032: 2015/AC: 2016, EN 61000-3-2: 2014, EN 61000-3-3: 2013, EN 55035: 2017, EN 62368-1: 2014 + A11: 2017.



The complete CE declaration of conformity of the product can be obtained by contacting Hamlet at info@hamletcom.com.
Visit www.hamletcom.com for complete information on all Hamlet products and to access downloads and technical support.
Imported by: CARECA ITALIA SPA - Scandiano (RE) . Italy.

Trademarks and changes

All trademarks and company names mentioned in this manual are used for description purpose only and remain property of their respective owners.
The material in this document is for information only. Contents, specifications and appearance of the product are indicative and may change without notice.

Description

Hamlet 4 Port USB 3.0 is an external Hub which adds four USB 3.0 ports to your computer. It supports up to 4 USB devices and complies with the new SuperSpeed USB 3.0 standard that offers a data transfer rate up to 5 Gbps, 10 times faster than USB 2.0.

System Requirements

- Windows 7/8/10 and 11, Mac OS 10.8 or above, Linux (kernel 3.0 and later)
- USB 3.0 port for USB 3.0 speed

Package content

- USB 3.0 Hub
- USB 3.0 Cable
- Power adapter (XHUB430BKPW only)
- User's manual

Installation and use

1. Connect the micro USB connector to Hub's micro USB 3.0 port with the USB cable supplied.
2. Connect the other end of the USB cable to a USB 3.0 port of your computer.
3. Only for XHUB430BKPW model, connect the power adapter to the Hub power connector and to the wall outlet.
4. Plug in your USB devices to the Hub's USB 3.0 ports.
5. The devices will mount in "My Computer" (Windows) or on your "Desktop" (Mac).

Connecting and disconnecting USB devices

Most USB devices can be removed and unplugged at will. When unplugging storage devices, such as USB flash drives, you should be sure that the computer has finished saving any information to the device before removing it. If the device has an activity light, wait for a few seconds after the light has finished flashing before unplugging it.

Windows Users

If you see the "Safely Remove Hardware" icon in the notification area at the far right of the taskbar, you can use this to ensure that devices have finished all operations in progress and are ready to remove.

1. Click the "Safely Remove Hardware" icon.
2. You'll see a list of connected devices.
3. Click the device you want to remove.

Mac Users

To eject a disk or volume, do one of the following:

- Select the item to eject and choose File > Eject.
- Drag the item to the Trash icon in the Dock (While you drag, the Trash icon changes to an Eject icon).